# Uddeholm Sleipner® Welding recommendations

## **GENERAL**

Uddeholm Sleipner is a new 8 % Cr-steel from Uddeholms AB. Its property profile has been carefully balanced and the result is a very versatile tool steel, which overcomes the limitations of the 12% Cr-steel such as AISI D2 or W.-Nr. 1.2379. The significantly better chipping resistance also result in better tool performance and easier maintenance. The machinability, grindability and hardenability are much better and it is easier to make small repair welds.

Good results when welding can be achieved if proper precautions are taken (joint preparation, choice of consumables and welding procedure).

# **RECOMMENDED FILLER MATERIAL**

Welding	Gas Tungsten Arc	Gas Metal Arc	Shielded Metal Arc	Laser	Comments
Method	Welding	Welding	Welding SMAW (MMA)		
	GTAW (TIG)	GMAW (MIG/MAG)			
Filler	Caldie TIG Weld	Dievar MIG Weld	UTP 690	Tyrax	
material	Unimax TIG WELD	QRO 90 MIG Weld	UTP 67S	Laser	
	UTP A696		UTP 73 G2	Weld	
	Тур	e	E 29 9 R		Use soft filler
	AWS E	R 312			material for buffering
	AWS ER N	NiCrMo-3			layer
Hardness	58 - 62 HRC Caldie	48 – 52 HRC	60-64 HRC UTP 690	55 – 60	
as welded	56 - 58 HRC Unimax		56-58 HRC UTP 67S	HRC	
	60 - 64 HRC A696		55-58 HRC UTP 73 G2		

## **DIMENSIONS FILLER MATERIAL**

Type	TIG		MIG	MMA			Laser	
Dia. Ø mm	1.0	1.6	2.4	1.2	2.5	3.25	4.0	0.2 - 0.6
Dia. Ø Inch	0.040	1/16	3/32	3/64	3/32	1/8	5/32	0.008 - 0.024
Caldie TIG Weld	Х	Х	Х					
Unimax TIG Weld		Х						
UTP A 696		Х						
Dievar MIG Weld				Х				
QRO 90 MIG Weld				Х				
UTP 690					Х	X	Χ	
UTP 67S					Х	Х	Х	
UTP 73 G2					Х	Х	Х	
Tyrax Laser Weld								Х

## **PARAMETERS**

Condition	Soft Annealed	Hardened	Comment
	215 HB	58 - 60 HRC	
Preheating	250°C ± 25°C	250°C ± 25°C	The temperature should be kept constant during
Temperature	480°F ± 50°F	480°F ± 50°F	the welding operation.
			Start with buffering layers if not all cracks are removed
Interpass	Max 150°C, 270°F	Max 150°C, 270°F	The temperature of the tool in the vicinity of the
temperature	above preheating	above preheating	weld.
	temperature	temperature	When passed, the tool will have a risk for
			distortion, soft zones or cracking in and around
			the weld (the HAZ).
Cooling rate	20 - 40°, 35 - 70°F	C/h The first 2 hours	
	then freely in a	air <70°C, 160°F	
Post treatment	Soft anneal	Temper 25°C, 50°F	Holding time when tempering, 2h. The
	Harden	below previous	temperature depends on the last used tempering
	Temper	tempering temperature	temperature.
			When soft annealing and hardening, see heat
			treatment specification in Uddeholm Sleipner
* Nata Walahawa a a a da at			product brochure.*

Note. We have seen that in many cases a high temperature tempering, 2h, of ~750°C (1380°F) functions instead of a complete soft annealing when welding in soft annealed material.

# **FLAME-/INDUCTION HARDENING**

Temperature	Post treatment	Surface hardness	Comment			
1000 - 1020°C 1830 - 1870°F	Cool freely in air		41 HRC at a depth of 3-3,5 mm when flame hardening and 10 mm when induction hardening on soft annealed material.			



## **PROCEDURES**

- Clean weld area.
- Preheat material to 250°C ± 25°C / 480°F ± 50°F and maintain temperature during welding.
- Do not let the temperature in the vicinity of the weld (the HAZ) increase more than 150°C / 270°F above the preheating temperature. There is a risk of lowering (softening) the hardness of the base material or/and cracking in the HAZ. Use temple sticks or other temperature-measuring devices.
- For finishing layers use consumables which give suitable hardness.
- Wait a few minutes between each layer of strings, both for soft and hard filler, in order to let the layer equalize and minimize stresses, if possible use preheating furnace. Peen to minimize stresses.
- If possible, change welding direction 180° between each layer.
- Cool slowly after welding, 20 40°C/h, 35 70 °F/h for the first two hours and then freely in air < 70°C / 160°F.</li>
- Temper 25°C / 50°F below previous tempering temperature for two hours.
- Tools welded in the annealed condition must undergo a full soft annealing immediately after welding. Allow tool to cool to room temperature before soft annealing. If a complete soft annealing cannot be done, which we recommend, a high temperature tempering at 750°C / 1380°F could be used. Be aware of that the working properties of the material will be somewhat reduced, if the high temperature tempering is used instead of the soft annealing.

# Dies welded in their production equipment.

This is something, which we <u>do not recommend</u>, but we are aware of that it happens and therefore we have made the following guideline.

Pre-heat, preferably with Propane, to at least 150°C / 300°F, around the area that are going to be welded. After finished welding, let the dies go down to < 70°C / 160°F. Do a second heating, preferably with Propane, to at least 200°C / 390°F.

Use these guideline recommendations along with "Welding of Uddeholm Tool Steel" for complete instructions.

